



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i



05012024

**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## CRANKCASE




REF #	DESCRIPTION	QTY	BE PART #
1	MAGNETIC DIPSTICK	1	85.561.043



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## CYLINDER HEAD COVER ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
1	CYLINDER HEAD COVER	1	85.561.099
2	STUDS BOLT	2+2	85.561.106
3	CYLINDER HEAD GASKET	1	85.561.100
4	EXHAUST PORT GASKET	1	85.561.107



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## ENGINE STARTER




REF #	DESCRIPTION	QTY	BE PART #
1	FAN SHROUD W/AIR FILTER	1	85.561.044
2	RECOIL ASSEMBLY	1	85.561.045



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## VALVE ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
1	VALVE ASSEMBLY	1	85.561.101



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## CARBURETOR PARTS




REF #	DESCRIPTION	QTY	BE PART #
1	CARBURETOR ASSEMBLY	1	85.561.046



# PARTS BREAKDOWN INVERTER GENERATOR


MODEL:BE2800i

## BACKPLANE / INVERTER



REF #	DESCRIPTION	QTY	BE PART #
1	INVERTER	1	85.561.047
2	SHOCK ABSORBERS	4	85.561.105
3	FEET W/HARDWARE	1	85.561.102

## PANEL




REF #	DESCRIPTION	QTY	BE PART #
1	COMBINATION SWITCH	1	85.561.049
2	CO ALARM	1	85.561.048
3	VOLTAGE REGULATING RECTIFIER	1	85.561.103



# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## RIGHT EXTERIOR COVER



REF #	DESCRIPTION	QTY	BE PART #
1	RIGHT COVER ASSEMBLY	1	85.561.104






# PARTS BREAKDOWN INVERTER GENERATOR

MODEL:BE2800i

## FUEL TANK COMPONENTS



REF #	DESCRIPTION	QTY	BE PART #
1	TANK CAP, FUEL FILTER, FILT TIP	1	85.561.050

# BE

**POWER EQUIPMENT**

---

If you need technical assistance call:

**1-866-850-6662**

(8:00am - 4:30pm PST, Mon - Fri)